



Feature Description Document

Configuring IXM Link for Keep by ACRE Security



Purpose

This document outlines the process of configuring IXM Link to sync users between Keep by ACRE Security and IXM WEB.

Applies to

TITAN	TFACE	TOUCH 2	SENSE 2	MERGE 2	MYCRO
All Devices	All Devices	All Devices	All Devices	All Devices	All Devices

Description

IXM Link is a licensed module in IXM WEB that helps to synchronize the user database between IXM WEB (from where biometric enrollment for users is performed) and leading Access Control Panel Software (from where access rules for the users and the organization are managed).

This FDD will describe how to set up and configure IXM Link if you are using Keep by ACRE Security to keep IXM WEB users in sync with the Keep system by using its APIs to import and export users and their cards.



Keep Module Activation

The option to activate an ACRE Security (Keep) License is available under the **License** tab.

STEP 1

Select **Settings** icon on top right of the page >> Click on **About IXM WEB** >> Click on **copy to clipboard** button next to **MACHINE KEY**.

Request a **License** by sending email to support@invixium.com. Paste the copied machine key in the email.


About IXM WEB ✕

VERSION 3.0.20.0
IXM WEB Copyright © 2024 Invixium.
All rights reserved.
Invixium [Terms of Service](#).

THIRD PARTY COMPONENTS
IXM WEB includes elements and components from Telerik's Kendo UI Web. Copyright © 2024, All rights reserved.

ANNUAL SUPPORT CONTRACT INFORMATION

Status	Expire On
Active	07/31/2025

MACHINE KEY 


B5k6X0y8NFfzQkuxy/kUBNHTNHVpc6yLgBoCitYxHdT25EuuoX4VHLR2Fps12MjHSj5VUgDHmYkLAwjAkxvag9EZ/0dujHSU4NfCykXOGbg=

[IXM WEB Activation](#) [What's New](#)




STEP 2

You will receive an email from Invixium Support containing a license key for the ACRE Security (Keep) Activation.



STEP 3

Navigate to **License** → Click on **IXM LINK** → **Copy** and **paste** the License Key in the box provided, and then select **Activate**.



IXM WEB is now licensed for use with Keep and configuration can begin.



Configuring Wiegand to Output ACRE Security

1. Register all IXM devices.
2. From **Devices** tab, select any device.
3. Navigate to the **Access Control** tab.
4. Scroll down and click on **Wiegand Output**.

The screenshot shows the 'Wiegand Output' configuration window. It features a list of events on the left and their corresponding settings on the right. The settings include dropdown menus for ID Type, Success, Failure, and Format, as well as text input fields for ID Value and Interval (sec). At the bottom, there are 'APPLY' and 'RESET' buttons.


Event	Setting	Value
Wiegand	ID Type	Employee ID
	Duress	None
Identification	Success	Standard 26 bit
	Fail	None
Verification	Success	Standard 26 bit
	Fail	None
Anti-Shock	Format	IXM 82 bit Device S/N
	ID Value	Device Serial Number
Heart Beat	Format	None
	ID Value	Device ID
Employee not found	Format	None
	Interval (sec)	60
Thermal Authentication	Format	Standard 26 bit
	Interval (sec)	2000
Mask Not Detected	Format	None
	Interval (sec)	2000
Invalid Attestation Questions	Format	None
	Interval (sec)	2000
PULSE (MSEC)		
Width	Interval	40 / 2000




5. Toggle the switch on the top right-hand side to enable Wiegand Output for the device.
6. Set ID Type of output Wiegand to Employee ID/Default/Actual Card. By default, Employee ID is selected in Wiegand Event.

Note: For fingerprint and face access, default card Wiegand output data will be generated


7. Select desired format for Identification, Verification, Employees not found, Thermal Authentication and Mask not Detected for the selected Card.
8. Click **Apply**.
9. This will update the Wiegand Output settings of the selected device.
10. If you have more devices, then follow the next steps to copy all Wiegand settings to all devices simultaneously. *Note: This copies all Wiegand output settings.*
11. To push these configurations to other Invixium readers, while the configured Invixium device is selected, click the **Broadcast** option from vertical ellipses button



12. Scroll down to the **Access Control** section → check **Wiegand Output** option → Click on **Broadcast**.



13. Select the rest of the devices in the popup. Click **OK** to copy all Wiegand output settings of the source device to all destination devices.





Field Mappings

The following are the Keep (ACRE Security) fields mapped with IXM WEB.


IXM LINK will only import or consider fields from Keep by ACRE Security that either have an exact counterpart in IXM WEB or have some bearing on imported data.

Keep (ACRE Security) Field	IXM Field	Notes
First name	First Name	
Last Name	Last Name	
Display Card Number (of card assigned)	Prox ID/Smart Card ID	A card in Keep is mapped to both Prox ID and Smart Card ID in IXM WEB. Prox ID is populated with the decimal representation of Display Card Number imported from Keep and Smart Card ID is populated with hexadecimal representation of card imported from Keep. While exporting, Prox ID is given preference when available otherwise Smart Card ID is converted to its decimal representation and set in Display Card Number.
PIN (of card assigned)	PIN	
Anti Passback Exempt (of card assigned)	Anti-Passback	

<p>Active On (of card assigned)</p>	<p>Start Date</p>	<p>Keep (ACRE Security) assigns 01/01/0001 when Active On is left blank which is not a valid value in IXM WEB hence LINK replaces it with 01/01/1753. When Start Date is left blank in IXM WEB, it's replaced with the date that the user was added to Keep while exporting the user for the first time. It's not assigned during the following updates which causes Keep (ACRE Security) to keep assigning 01/01/0001.</p>
<p>Expires On (of card assigned)</p>	<p>End Date</p>	<p>Keep (ACRE Security) assigns 01/01/0001 when Expires On is left blank which is not a valid value in IXM WEB hence LINK replaces it with 01/01/1753. When End Date is left blank in IXM WEB, it's replaced with the time when the user was added to Keep while exporting the user for the first time. It's not assigned during the following updates which causes Keep (ACRE Security) to keep assigning 01/01/0001.</p>

Configuring LINK for ACRE Security

1. Navigate to **Link** → click the **Keep (ACRE Security)** icon.



2. Enable editing configuration by toggling the status switch next to the logo to **ON**. Data is not synced when the configuration is applied with this switch in the OFF position.
3. Provide values for the Web Service URL, Instance Name, User, Password, Interval, Sync Direction, Auto Transfer option, and Sync Card Number fields. Each configuration setting is explained below:

Web Service URL: ACRE Security API URL.

Instance Name: ACRE Security Instance Name.

User: Name to log in to Keep by ACRE Security.

Password: Password to log in to Keep by ACRE Security.

Interval: Latency acceptable between data transfers.



Sync Direction:

- Sync data from Keep to IXM WEB.
- Sync data from IXM WEB to Keep.
- Sync data both ways. LINK will update IXM WEB first and then Keep.

Auto Transfer:

- No: Employees synchronized from Keep will not be automatically added to any of the employee groups present in IXM WEB.
- Yes: By selecting 'Yes' for Auto Transfer, the employee group selection dropdown enables which displays all the employee groups present in IXM WEB. All the employees synchronized from Keep will be automatically added to the employee group selected on the Link Configuration Page.

Employee Group: Selection of employee group needs to be done to use the Auto transfer functionality.

4. Click **Apply** to save the settings.
5. When synchronization happens at the specified intervals and the users are added or updated, the numbers will change accordingly.
6. For immediate syncing instead of at the specified automatic intervals click the “Sync Now” button which runs immediate sync.

The screenshot shows a dashboard titled "ACTIVITIES" with three main sections: "Numbers", "Numbers in IXM WEB", and "Times". Each section contains three data points: "Added", "Updated", and "Deleted". The "Numbers" section shows 0 for all three. The "Numbers in IXM WEB" section also shows 0 for all three. The "Times" section shows "-" for "Last run at" and "Next run at". Below these sections is a red "Sync Now" button.

Numbers			Numbers in IXM WEB			Times	
0	0	0	0	0	0	-	-
Added	Updated	Deleted	Added	Updated	Deleted	Last run at	Next run at

[Sync Now](#)

7. Here you can see data pertaining to license usage with last and next run times.



8. Clicking **Sync Now** immediately syncs pending data. This is useful when you don't want to wait until the next scheduled run which is shown in Next Run At.
9. When data is syncing at the given interval, the numbers in the Activity log will change accordingly.



Multiple Cards

ACRE Security can have multiple cards per user but IXM WEB supports only one card. Link selects the first available valid card.



Support

For more information relating to this Feature Description document, please contact us at support@invixium.com

Disclaimers and Restrictions

This document and the information described throughout are provided in their present condition and are delivered without written, expressed, or implied commitments by Invixium Inc. and are subject to change without notice. The information and technical data herein are strictly prohibited for the intention of reverse engineering and shall not be disclosed to parties for procurement or manufacturing.

This document may contain unintentional typos or inaccuracies.

TRADEMARKS

The trademarks specified throughout the document are registered trademarks of Invixium Access Inc. All third-party trademarks referenced herein are recognized to be trademarks of their respective holders or manufacturers.

Copyright © 2024, INVIXIUM. All rights reserved.